
How to Remove Mercury Switches in Hood and Trunk Lights



Chrysler/Dodge





Remove the light blub.



Clip the wire at the base of the light assembly.



Push the mercury switch out of the light assembly. The mercury switch will come out through the socket.







Remove the light bulb.



Pry the light assembly in half.



Remove the mercury switch from its housing.



